

Although the surface of washbasins is well protected against external effects, daily and regular care of the washbasin will extend its service time and keep it hygienic.

1. For a proper care use regular cleanser without abrasive particles for the surface of the washbasin using a soft sponge or cloth.
2. Rinse it with warm water.
3. Dry out and clean water stains from the surface.

From time to time, clean the washbasin with recommended AQUASANITA CARE cleanser.

Do not use abrasive detergents as it might cause the damage of the washbasin surface.

GELCOAT WASHBASINS CARE

GELCOAT WASHBASINS are safe, comfortable and durable, matching the highest quality standards. The surface of the washbasins is smooth, shiny and dirt resistant.

CLEANING AND MAINTENANCE RECOMMENDATIONS:

- > we recommend cleaning the washbasin with a soft damp cloth or a sponge;
- > non-alkaline and abrasive free materials may be used;

IMPORTANT!

In the event of difficult stains (mascara, lipstick, hair dye and other cosmetics), we recommend that you wash them immediately with warm water and clean with non-alkaline and abrasive free cleansers. After removing dirt from the washbasin, dry the surface.

NOT RECOMMENDED:

- > leaving hot objects (hair styling devices, etc.) on the washbasin surface.